

HI THERE!

THANK YOU FOR CHOOSING GO PADDLE MTL FOR YOUR WATER ADVENTURES

We are a small team passionate about the outdoors and having fun on the water. We are dedicated to offering you the best possible experience with our products. Just a friendly reminder to take all safety precautions on your adventures and don't hesitate to share your pictures and videos with us!



For more information or assistance, contact-us: gopaddlemtl@gmail.com

GO10' / GO10.5' / GO10.5' BW / GO11' / GO11' W

included:


- storage bag
- paddle
- removable fin
- manual pump
- safety leash
- repair kit

Specifications

GO 10' : 10' x 30" x 6"
Maximum capacity: 310 lbs

GO 10.5' : 10'6" x 32" x 6"
Maximum capacity: 330 lbs

GO 11' : 11' x 32" x 6"
Maximum capacity: 350 lbs



INSTRUCTIONS

- Unwrap and unroll the board on a clean, flat surface
- Unscrew the cap on the inflation valve
- Connect the flexible hose to the pump and to the inflation valve
- Ensure the valve is in the elevated position so that air stays in (closed position).
- Inflate the board.
- The pressure gauge on the pump will indicate the PSI level of the board
- Disconnect the hose from the valve.
- Screw the cap on the inflation valve
- Install the safety leash onto the anchor that is near the valve
- Install the central fin and make sure it is clipped in properly
- Assemble the paddle and adjust to the desired length
- Take the board out of the water to deflate.
- Press the inflation valve down and turn it so it stays down (opened position).
- Allow the board to dry completely before storing it to avoid mold or mildew accumulation over time

CAUTION!

- Respect the maximum weight limit on the board
- Overinflating may cause damages to the board
- We recommend deflating and storing your board if you do not plan to use it for long periods of time.
- Rinse your board with water after use especially if you go on a variety of bodies of water.

Go Paddle Mtl offers a limited warranty of 1 year for this product, applicable only on manufacturing defects that make the product unusable. The warranty does not apply for the following:

- Wear and tear and discoloration of materials due to normal usage and environmental exposure
- Damage caused by abuse or lack of proper maintenance
- Damage caused by an impact or collision
- Damage caused by mooring and storing of the board
- Damage caused by transporting the board and its accessories
- A board used for rentals or resale

If you have any questions or concerns about this product and its accessories, contact us first, it will be our pleasure to help you: gopaddlemtl@gmail.com